




TOP AND CONSOLE PARTS

For Models: GGW9868KQ3, GGW9868KL3, GGW9868KT3
(Designer White) (Pewter) (Biscuit)

27" GAS DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

TOP AND CONSOLE PARTS


For Models: GGW9868KQ3, GGW9868KL3, GGW9868KT3
 (Designer White) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1		Literature Parts	7	3395683	Connector (Motor)	22		Cap, End (L.H.)
	8528148	Guide, Use & Care	8		Cap, End (R.H.)		8299683	White
	3979174	Instructions, Installation		8299686	White		8299685	Pewter
	8541837	Tech Sheet		8299688	Pewter		8299684	Biscuit
Following May Be Purchased								
DO-IT-YOURSELF REPAIR MANUALS								
	677818	Manual, Do-It- Yourself Repair (Dryer)	9	8299690	Bracket, Control	23	3936144	Connector
2	8274338	Panel, Rear Console	10	8316751	Medallion	24	3403498	Connector, 3-Position (Gas Valve)
3	3980061	Control Board	11	3401850	Harness, Gas	26	2203186	Connector
4	8318255	Console Strap	12	3400073	Screw, 10-24 x 5/16	27	3936150	Connector, 7-Circuit
5	304231	Screw, 8-16 x 1/2	13	3400826	Screw, 8-18 x 3/4	28	3394427	Clip, Harness
6		Panel, Console (Includes Keyswitch)	14	3391018	Tie, Cable (Push-Mount)	29	94614	Terminal Medallion
	3978825	Pearl	15	693995	Screw, 8-18 x 3/8	30		Assembly
	3978826	Pewter	16	353424	Connector		8521943	Sage
			17	717252	Receptacle, 2-Way		8521944	Pewter
			18	3403499	Connector, 2-Position (Gas Valve)	31	3406653	Harness, Sensor
			19	8299949	Harness, Wiring	32	8317340	Cover, Terminal Block
			20	357213	Nut, Push-In (2)	33	3390814	Screw, 8-18 x 3/8
			21		Top	34	8312709	Clip, Console
				3978832	White			
				3978837	Pewter			
				3978833	Biscuit			

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GGW9868KQ3, GGW9868KL3, GGW9868KT3
(Designer White) (Pewter) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

CABINET PARTS

For Models: GGW9868KQ3, GGW9868KL3, GGW9868KT3
 (Designer White) (Pewter) (Biscuit)


Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	697773	Screw, 6-20 x 7/8	20	690997	Tri Ring	46	3388229	Retainer
2	8529757	Bracket, Burner	21	3387560	Hinge, Door (R.H.)	47	697655	Door, Rear
4	3394331	Plate, Cover		3387559	Hinge, Door (L.H.)	48	694091	Screw, 8-18 x 3/8
5	3394881	Switch, Broken Belt	22	3387565	Spring, Door (2)	49		Door, Front
6	344020	Cord, Power Cabinet	23	8066120	Lever, Snap Switch		8521938	White
7	8310656	White	24	3394081	Wire, Belt Switch		8521936	Pewter
	8528155	Pewter	25	49026	4" - 90° Elbow		8521939	Biscuit
	8310659	Biscuit	26	3393657	Restrainer, Belt	51		Upper Front Panel
8	3392100	Foot, Dryer	27	8538263	Motor, Assembly 60 HZ.		697227	White
	279810	Foot - Optional (Extended Length Package Of 2) (Not Included)	28	3395534	Exhaust Pipe (Short)		3979198	Pewter
9	660658	Clamp, Motor (2)	29	3389729	Pulley 60 HZ.		3977761	Biscuit
10	3387374	Spring, Idler	30	3387610	Belt, Drive	52	696144	Strike, Door
11	3389420	Retainer, Idler	31	8281212	Screw, 8-18 x 3/8	57	3390736	Seal, Door
12		Plug, Multivent 697750 White	32	3387118	Bracket, Motor	58	690081	Catch, Door Assembly
	3979261	Pewter	33	3395535	Exhaust Pipe (Long)	60		Handle, Door
	3388311	Biscuit	34	693152	Bumper		8521931	Sage
13	3388672	Pulley Assembly	35	98129	Screw, 6-20 x 1 3/8		8521932	Pewter
14	3390663	Screw, 10-16 x 1/2	36	693995	Screw, 8-18 x 3/8	61		Toe, Panel (Includes Illus. 34)
15	697776	Screw, Ground	37	3406911	Dry Rack Assembly		697215	White
16	3398948	Wire, Jumper (Broken Belt Switch)	38	3406910	Dry Rack (Top)		3979197	Pewter
17	3395532	Exhaust Pipe & Bracket	39	3388674	Idler Bracket		3977764	Biscuit
18	233520	Washer, Thrust	40	3357011	Screw, 10-16 x 1/2			
19	297092	Clip (2)	41	3406107	Door Switch Assembly			
			42	3406908	Dry Rack (Bottom)			
			44	3387242	Seal, Front Panel			
						62	279818	White
							279969	Pewter
							279925	Biscuit

Optional Parts Not Included

Dryer Exhaust Kit (For Side & Bottom Venting)

BULKHEAD PARTS

For Models: GGW9868KQ3, GGW9868KL3, GGW9868KT3
(Designer White) (Pewter) (Biscuit)



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

BULKHEAD PARTS

For Models: GGW9868KQ3, GGW9868KL3, GGW9868KT3
 (Designer White) (Pewter) (Biscuit)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
1	3399508	Shaft, R.H. Thread	15	8318486	Exhaust Pipe	36	3406124	Bulb, Light
2	3390647	Screw, 8-18 x 1/2	16	3387709	Nut, 3/8-16 (L.H.)	37	697772	Wheel, Blower
3	90767	Screw, 8-18 x 3/8	17	8520836	Bulkhead, Rear	42	3976615	Thermostat, Internal Bias
4	3394986	Spring, Lint Screen Door	18	3387459	Washer, Support	43	3403140	Thermostat, High-Limit 205°F (96°C)
5	3394346	Air Duct Assembly	19	3399509	Shaft, L.H. Thread	44	8544362	Housing, Blower
6	697813	Seal, Outlet Housing	20	690997	Ring, Tri	45	8066168	Lint Duct Assembly
7	697814	Seal, Drum Front	21	8536973	Roller, Support	46	8066047	Funnel, Burner
8	3359452	Nut, 3/8 x 16(R.H.)	22	3390646	Screw, 8-18 x 5/16	48	338906	Sensor, Radiant
9	8066086	Drum Hole Plug	23	3394985	Outlet Housing Assembly	51	3387230	Screw, 10-16 x 1
10	3402841	Lens, Drum Light	24	359625	Screw, 8-18 x 1/2	53	697693	Baffle, Drum
11	3403634	Socket Assembly	25	8318215	Complete Drum Assembly	54	697557	Bulkhead, Front
12	487909	Screw, 8-15 x 1/2	26	97787	Screw, 11-16 x 3/4	58	8299979	Grill, Outlet
13	695240	Screw, 8-18 x 1/2	27	697694	Seal, Drum	59	3392519	Thermal Fuse
14	3394984	Door, Lint Screen	30	3388229	Clip, Exhaust	60	697770	Seal, Cover Plate
			34	3387223	Electrode, Sensor	64	8066170	Lint, Screen
			35	3977373	Bracket, Drum Light			

OPTIONAL PARTS (NOT INCLUDED)

Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION	Illus. No.	Part No.	DESCRIPTION
ACCESSORY PARTS								
PAINT, TOUCH-UP (1/oz.)								
4392067	Kit, Dryer Repair	72017 White	4396174	Pewter		799344	White (Uncut)	
8522199	Kit, Dryer Vent Testing	4392899 Biscuit	4392900	Biscuit(Uncut)				
346764	Kit, Hold-Down (Gas Dryer Mobile Home Installation)	PAINT, PRESSURIZED SPRAY (12 oz.)						
		350930 White						
		4396175 Pewter						
		4392901 Biscuit						
		350938 Primer, Gray						


FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

8318276 BURNER ASSEMBLY

For Models: GGW9868KQ3, GGW9868KL3, GGW9868KT3
(Designer White) (Pewter) (Biscuit)

USE WITH TYPE 1 - NATURAL

AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

8318276 BURNER ASSEMBLY

For Models: GGW9868KQ3, GGW9868KL3, GGW9868KT3
(Designer White) (Pewter) (Biscuit)

USE WITH TYPE 1 – NATURAL
AND TYPE 4 LIQUEFIED PROPANE AND BUTANE GASES

Illus.	Part	
No.	No.	DESCRIPTION
1	8318276	Burner Assembly 60 Hz. (Type 1) (White Rodgers)
2	688617	Tube, Burner
3	694298	Bracket, Ignitor
4	686590	Ignitor
5	3393909	Screw & Washer (8-32 x 7/8)
6	343641	Screw, 10-16 x 1/2
7	3389871	Base, Burner
8	3387057	Screw, 8-18 x 3/8
9		Orifice, Burner
	234826	Type 1
	229742	Type 4 (Butane)
	234868	Type 4 (Propane)
10	8318281	Valve, Gas 60 Hz. (Complete) (Includes Pipe & Illus. #7).
11	694421	Screw, 8-32 x 1/2 (2)
12	694538	Bracket, Coil
13	694540	Coil, 60 Hz. (2 Terminal) (Main)
14	694539	Coil, 60 Hz. (Split) (3 Terminal) (Pilot Position)
15	694424	Leak, Limiter
16	694423	Screw, Regulator Adjustment
17	694422	Spring, Regulator
18	3390647	Screw, 8-18 x 1/2
20	239822	Plug, Pipe
25	3387561	Clamp, Pipe
26	3389889	Bracket, Support

Following Parts Not Illustrated

694572 Conversion Kit
(Type (1)
to Type (4) LPG).